



12 VOLT AUXILIARY BATTERY

This supplies all the Electric Vehicle's accessories. It is charged by the traction battery via a "converter" which acts as an alternator.

Disconnecting the 12 volt battery is not recommended.

If this is necessary, disconnect the (-) terminal then the (+) terminal, isolate the terminals from each other and from the vehicle earth.

Only disconnect the 12 volt battery for a limited period.

There is no need to disconnect the 12 volt battery if the vehicle is being taken off the road.

SAFETY

Never place a naked flame or create sparks near the 12 volt battery (explosive gas).

The battery contains dilute sulphuric acid which is corrosive.

When carrying out any work, protect the eyes and face.

It is essential to switch off the ignition, remove the key and apply the handbrake firmly before leaving your Electric Vehicle.

With the ignition off, braking is no longer power-assisted.